

REVOLUTIONARY REVO!

ACTIVATE YOUR
REVO IN SECONDS!

ACTIVATION MADE EASY

- **Tools Included:** Activation Key | Zip Tie | Velcro
- **Location:** Find a place within the vehicle to securely mount your device. This helps avoid the device from shifting.

DEVICE ACTIVATION

- Insert the activation key and hold for 10 seconds.
- Remove the activation key and you will see the LED's turn on and go solid. LED lights will shut off ~ 10 seconds after activation process.

OPTIMAL LOCATION OPTIONS TO SECURE YOUR ACTIVE DEVICE

- Under vehicle dashboard or center console
- Behind bench seat, under carpet
- In trunk | cab wall
- Under rear seat



Activation key



Insert Key

Remove Key,
LED lights
come on



Be sure the device has a good line of sight to the sky with no metal obstructions above it.

Advantage®
AutoMatic Analytics